















# ALTERNATOR-FRAMES

## BOSCH

<p><b>AHBO-225(DE)</b></p>  <p>Description: ID: 145mm Bearing Bore Dia: 52mm Foot to Bearing Center: 2-R90 2-Φ11</p>	<p><b>AHBO-226(SRE)</b></p>  <p>Description: ID: 145mm Bearing Bore Dia: 43mm</p>	<p><b>AHBO-303(SRE)</b></p>  <p>Description: ID: 138mm Bearing Bore Dia: 32mm</p>
<p><b>AHBO-387(DE)</b></p>  <p>Description: ID: 138mm Bearing Bore Dia: 47mm Foot to Bearing Center: R89 Φ10.6 R90 Φ10.6</p>		

# ALTERNATOR-FRAMES HITACHI

<p><b>AHHI-043A(DE)</b> R84.5 M8 R90 <math>\Phi</math> 10.5 124MM Description:ID:124mm Bearing Bore Dia: 47mm Foot to Bearing Center:R90 <math>\Phi</math>10.5 R84.5 M8</p> 	<p><b>AHHI-043B(DE)</b> R84.5 M8 R90 <math>\Phi</math> 10.5 124MM Description:ID:124mm Bearing Bore Dia: 47mm Foot to Bearing Center:R90 <math>\Phi</math>10.5 R84.5 M8</p> 	<p><b>AHHI-043C(DE)</b> R84.5 M8 R90 <math>\Phi</math> 10.5 124MM Description:ID:124mm Bearing Bore Dia: 47mm Foot to Bearing Center:R90 <math>\Phi</math>10.5 R84.5 M8</p> 
<p><b>AHHI-044(SRE)</b> R90 <math>\Phi</math> 16 124MM Description:ID:124mm Bearing Bore Dia: 32mm Foot to Bearing Center:R90 <math>\Phi</math>16</p> 	<p><b>AHHI-448(DE)</b> R88 M12 R88.5 <math>\Phi</math> 14.5 121MM Description:ID:121mm Bearing Bore Dia:62mm Foot to Bearing Center:R88 M12 R88.5 <math>\Phi</math>14.5</p> 	<p><b>AHHI-449(SRE)</b> R88.5 <math>\Phi</math> 20 121MM Description:ID:121mm Bearing Bore Dia: 35mm Foot to Bearing Center:R88.5 <math>\Phi</math>20</p> 
<p><b>AHHI-450(DE)</b> R100 <math>\Phi</math> 12.5 R100 <math>\Phi</math> 14.5 121MM Description:ID:121mm Bearing Bore Dia: 62mm Foot to Bearing Center:2-R100 <math>\Phi</math>12.5 <math>\Phi</math>14.5</p> 	<p><b>AHHI-451(DE)</b> R100 <math>\Phi</math> 20 121MM Description:ID:121mm Bearing Bore Dia: 35mm Foot to Bearing Center:R100 <math>\Phi</math>20</p> 	<p><b>AHHI-464(DE)</b> R85 M8 R90 <math>\Phi</math> 10.5 135MM Description:ID:135mm Bearing Bore Dia: 47mm Foot to Bearing Center:R90 <math>\Phi</math>10.5 R85 M8</p> 
<p><b>AHHI-465(SRE)</b> R90 <math>\Phi</math> 15 135MM Description:ID:135mm Bearing Bore Dia:35mm Foot to Bearing Center:R90 <math>\Phi</math>15</p> 		

# ALTERNATOR-FRAMES MITSUBISHI

<p><b>AHMI-255(DE)</b></p> <p>Description: ID:126mm Bearing Bore Dia:47mm Foot to Bearing Center:R89.5 Φ8.2 R87 M8</p>	<p><b>AHMI-256(SRE)</b></p> <p>Description: ID:126mm Bearing Bore Dia:35mm Foot to Bearing Center:R89.5 Φ16</p>	<p><b>AHMI-455(DE)</b></p> <p>Description: ID:138mm Bearing Bore Dia:62mm Foot to Bearing Center:2-R95 Φ12 M12X1.25</p>
<p><b>AHMI-456(SRE)</b></p> <p>Description: ID:138mm Bearing Bore Dia:42mm Foot to Bearing Center:R95 Φ22</p>	<p><b>AHMI-715(DE)</b></p> <p>Description: ID:126mm Bearing Bore Dia: 47mm Foot to Bearing Center:R82.5 Φ8.7 R79 Φ9.2</p>	<p><b>AHMI-716(SRE)</b></p> <p>Description: ID:126mm Bearing Bore Dia:23mm Foot to Bearing Center:R82.5 Φ9</p>
<p><b>AHMI-777(DE)</b></p> <p>Description: ID:126mm Bearing Bore Dia: 47mm Foot to Bearing Center:R85 Φ9 R90 Φ10.5</p>	<p><b>AHMI-778(SRE)</b></p> <p>Description: ID:126mm Bearing Bore Dia:23mm Foot to Bearing Center:R90 Φ17</p>	<p><b>AHMI-812(DE)</b></p> <p>Description: ID:119mm Bearing Bore Dia: 47mm Foot to Bearing Center:R85 M8 R81 M8</p>
<p><b>AHMI-813(SRE)</b></p> <p>Description: ID:119mm Bearing Bore Dia: 26mm Foot to Bearing Center:R81 Φ17</p>	<p><b>AHMI-002A(DE)</b></p> <p>Description: ID:133mm Bearing Bore Dia: 47mm Foot to Bearing Center: Ø8.5</p>	<p><b>AHMI-002B(SRE)</b></p> <p>Description: ID:133mm Bearing Bore Dia: 23mm Foot to Bearing Center: Ø8.5</p>
<p><b>AHMI-019A(DE) MAZDA 90A</b></p> <p>Description: ID:126mm Bearing Bore Dia: 47mm Foot to Bearing Center: Ø10.5 M8-7H</p>	<p><b>AHMI-019B(SRE) MAZDA 90A</b></p> <p>Description: ID:126mm Bearing Bore Dia: 35mm Foot to Bearing Center: Ø17</p>	<p><b>AHMI-047A(DE) NISSAN SUNNY 2.0</b></p> <p>Description: ID:126mm Bearing Bore Dia: 47mm Foot to Bearing Center: Ø10.5 M8-7H</p>
<p><b>AHMI-047B(SRE) NISSAN SUNNY 2.0</b></p> <p>Description: ID:126mm Bearing Bore Dia: 23mm Foot to Bearing Center: Ø10.5</p>	<p><b>AHMI-100A(DE)</b></p> <p>Description: ID:140mm Bearing Bore Dia: 47mm Foot to Bearing Center: Ø10.5 Ø10 M8-7H</p>	<p><b>AHMI-100B(SRE)</b></p> <p>Description: ID:140mm Bearing Bore Dia: 27mm Foot to Bearing Center: Ø10.5</p>








# ALTERNATOR-FRAMES NIPPONDENSO

<p><b>AHND-053A(DE)</b></p> <p>R88 M8 121 MM R88 Φ10.4</p> <p>Description:ID:118mm 121mm Bearing Bore Dia:47or52mm Foot to Bearing Center:R88 M8 R88 Φ10.4</p>	<p><b>AHND-053B(DE)</b></p> <p>R88 M8 121 MM R88 Φ10.4</p> <p>Description:ID:118mm 121mm Bearing Bore Dia:47or52mm Foot to Bearing Center:2-R88 Φ10.4 M8</p>	<p><b>AHND-054(SRE)</b></p> <p>R87.5 Φ18</p> <p>Description:ID:121mm Bearing Bore Dia:35mm Foot to Bearing Center:R88 Φ18</p>
<p><b>AHND-073(DE)</b></p> <p>R78 M8 102MM R78 Φ8.5</p> <p>Description:ID:100mm 102mm Bearing Bore Dia: 35mm Foot to Bearing Center:R78 Φ8.5 R78 M8</p>	<p><b>AHND-074A(SRE)</b></p> <p>R78 Φ13.5 102MM Φ13.5XΦ8.5X15.5</p> <p>Description:ID:102mm Bearing Bore Dia: 32mm Foot to Bearing Center:R78 Φ13.5</p>	<p><b>AHND-195(DE) รถตู้-80A</b></p> <p>R84 M8 121 MM R80 Φ10.3</p> <p>Description:ID:118mm 121mm Bearing Bore Dia:40mm Foot to Bearing Center:R80 Φ10.3 R84 M8</p>
<p><b>AHND-196(SRE) รถตู้-80A</b></p> <p>R80 Φ10.6 121MM Φ6.6X5X38.5</p> <p>Description:ID:121mm Bearing Bore Dia:35mm Foot to Bearing Center:R80 Φ10.6</p>	<p><b>AHND-373(DE)</b></p> <p>R83 Φ10.3 133 MM R86 M8</p> <p>Description:ID:130mm 133mm Bearing Bore Dia:52mm Foot to Bearing Center:R83 Φ10.3 R86 M8</p>	<p><b>AHND-374(SRE)</b></p> <p>R83 Φ10.6 133 MM Φ6.6X5X29</p> <p>Description:ID:133mm Bearing Bore Dia: 35mm Foot to Bearing Center:R83 Φ10.6</p>
<p><b>AHND-556(DE)</b></p> <p>Ø8.3 128.5MM 80.5MM 81MM Ø8.8</p> <p>Description:ID:128.5mm Bearing Bore Dia: 47mm Foot to Bearing Center:R80.5 Φ8.3 R81 Φ8.8</p>	<p><b>AHND-557(SRE)</b></p> <p>128.5 MM 80.5 MM Ø9</p> <p>Description:ID:128.5mm Bearing Bore Dia:35mm Foot to Bearing Center:R80.5 Φ9</p>	<p><b>AHND-771(DE)</b></p> <p>R86 M8 128.5MM R83 Ø10.5</p> <p>Description:ID:128.5mm Bearing Bore Dia: 47mm Foot to Bearing Center: R83 Φ10.5 R86 M8</p>
<p><b>AHND-772(SRE)</b></p> <p>128.5MM R83Ø18.3 Ø25.8XØ18.3XØ11.5X17.5</p> <p>Description:ID:128.5mm Bearing Bore Dia: 35mm Foot to Bearing Center:R83 Φ18.3</p>	<p><b>AHND-608(DE)</b></p> <p>R90 Φ12.8 121 MM R90 Φ11</p> <p>Description:ID:118mm 121mm Bearing Bore Dia: 52mm Foot to Bearing Center:2-R90 Φ11 Φ12.8</p>	<p><b>AHND-609(SRE)</b></p> <p>R90 Φ18 121 MM Φ6.6X5X38.5</p> <p>Description:ID:121mm Bearing Bore Dia: 35mm Foot to Bearing Center:R90 Φ18</p>
<p><b>AHND-042A(SRE)</b></p> <p>M8-7H 118 MM φ10.5</p> <p>Description: ID:118mm Bearing Bore Dia: 52mm Foot to Bearing Center: φ10.5 M8-7H</p>	<p><b>AHND-042B(DE)</b></p> <p>118 MM φ10.5</p> <p>Description: ID:118mm Bearing Bore Dia: 35mm Foot to Bearing Center: φ10.5</p>	<p><b>AHND-077A(SRE) CAMRY</b></p> <p>φ11 128.5 MM M8-7H</p> <p>Description: ID:128.5mm Bearing Bore Dia: 47mm Foot to Bearing Center: φ11 M8-7H</p>



# ALTERNATOR-FRAMES

## NIPPONDENSO

<p><b>AHND-077B(DE) CAMRY</b></p>  <p>Description: ID:128.5mm Bearing Bore Dia: 35mm Foot to Bearing Center: M10X1.25</p>	<p><b>AHND-221A(SRE)</b></p>  <p>Description: ID:130mm Bearing Bore Dia: 52mm</p>	<p><b>AHND-056B(DE)</b></p>  <p>Description: ID:130mm Bearing Bore Dia: 35mm Foot to Bearing Center: ø10.5</p>
<p><b>AHND-D4D1 VIGO</b></p>  <p>ø7</p>	<p><b>AHND-D4D2 VIGO</b></p>  <p>ø11</p>	

# ALTERNATOR-FRAMES

## SAWAFUJI

<p><b>AHSW-400(DE)</b></p>  <p>Description:ID:150mm Bearing Bore Dia: 62mm Foot to Bearing Center:2-R110 M10 Φ14</p>	<p><b>AHSW-401(SRE)</b></p>  <p>Description:ID:150mm Bearing Bore Dia: 23.8mm Foot to Bearing Center:R110 Φ20</p>	